

WarmMark Instructions





STORAGE: For best shelf-life, store WarmMark in a cool dark environment between 35-55% RH at least 5°C below the response temperature.

PRECONDITIONING: Ensure WarmMark and your goods are stabilized at least 5°C below the response temperature when you pull the activation tab.

ACTIVATION and APPLICATION: To arm, pull the tab all the way out. Place the indicator on or in your goods using the self-adhesive back. Return your monitored goods to the preconditioned temperature for storage or until shipment to avoid premature readout.

INDICATION: Presence of pink or red in the clear windows indicates a temperature breach.

http://telatemp.com